

Quick Start Guide

GF1082 V3.2.0



PipeBurst Pro™ 4

Automatic Water Protection Systems



To sign up for app.ionleaks.com please visit

www.app.ionleaks.com/signup

www.PipeBurstPro.com

800-246-LEAK (5325)



1. Create a new account using the "Create a new account" link at https://app.ionleaks.com/users/sign_in
2. Fill in all requested information and click the "SIGN UP" button to create your account.
3. Follow link in email from help@greenfielddirect.com
4. Sign into app.ionleaks.com.
5. On left side of page, click "Systems".
6. On Systems page, click "Claim System".
7. Enter VIP Serial number for the system you wish to claim and click "Claim".

For full app.ionleaks.com user manual, visit <http://www.pipeburstpro.com/support/>

FloTrax
(front)




- P. LED Status Light
- Q. TickerValve On/Off Button
- R. AC Power Port
- S. Wired Sensor Jack

Repeater
(back)




- R. AC Power Port
- U. Wired Sensor Jack
- V. Sensor Pins
- W. Sync Button
- X. Serial Number

Wireless Water Sensor
(back)



- W. AC Power Port
- Y. Wired Sensor Jack
- AA. Sensor Pins
- BB. Sync Button
- CC. AA Battery Housing
- DD. Serial Number

Wired Water Sensor



- EE. Wired Cord (5 or 20 ft)
- FF. Stainless Steel Body
- GG. Sensor Pads

Customer Support:

GreenField Direct, LLC

14015 238th Street

Greenwood, NE 68366

<http://www.pipeburstpro.com/contact/>

Phone: 800-246-LEAK (5325)

Fax: (402) 944-2907

E-Mail: info@GreenFieldDirect.com

Operating Hours: Monday - Friday, 8:00am - 5:00pm CST (Excludes Major Holidays)

Warranty - PipeBurst Pro Products 7 Year Limited Warranty -

GreenField Direct, LLC of 14015 238th St, Greenwood, NE 68366 ("Warrantor"), warrants to the original purchaser and installed location of the PipeBurst Pro, manufactured by Warrantor, and to any person to whom such originally installed equipment is transferred to via the transfer of said real property that original installation was made, that such equipment shall be free from defects in materials and workmanship during a two (2) year period; additionally the electric valve actuator enclosure and its' electronic components inside, shall be free from interior moisture damage for a period of seven (7) years; both periods commencing upon the receipt of order date for such equipment from the original purchaser thereof; (the "warranty periods"). Product should be registered to be covered by warranty.

Note: Please register the PipeBurst Pro to activate your warranty

<http://www.pipeburstpro.com/support/warranty-registration/>

FCC Compliance Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Power Requirements:

- For Indoor Use Only (Except TickerValve)
- Requirements for US & Canada
- Use supplied AC Adapter or AC Adapters purchased from PipeBurst Pro Dealer

VIP Sr.	
Input	100-240V ~50/60Hz 1.0A MAX
Output	18V DC 2.22A
Remote Control / Repeater / Water and Temperature Device	
Input	100-240V ~50/60Hz 0.2A MAX
Output	5V DC 1.2A



To sign up for app.ionleaks.com please visit

www.app.ionleaks.com/signup

www.PipeBurstPro.com

800-246-LEAK (5325)